
## Vent & Breather Check Valves





- ▶ Vent Assembly (2" NPT) has a one-way check valve on air discharge which allows venting over 300 GPM diesel fueling rate and prevents air from entering tank through the vent opening.
- Only filtered air (recommended 3 Micron) is allowed into the diesel fuel tank, check valve on breather filter prevents diesel fuel contacting the filter media.
- All-metal construction.



## FFV 150 Remote Mount Filter Vent




- Low profile for variable placement
- Only 8" inches in height
- Universal mounting bracket for easy installation

## FFV150-HV High Volume Filter Vent



- Ideal for large storage tanks
- Enlarged Filter Check Valve



## FFV150-VB1

